



78-2249 (x4)
(bolt 1/2-20 x 7/8")

78-2102
(conduit clamp)

24309-S8 (x2)
(bolt 1/4 -28 x 1/2 ")

78-2019-F (x2)
(shoe/lining assy)

78-2296-A
(spring blk)

78-2042 (x2)
(adjusting link)

78-2034-A
(spring red)

78-2036
(spring 5.68")

78-2069(x2)
(pin)

78-2071 (x2)
(spring cup)

78-2068 (x2)
(spring)

78-2067 (x2)
(spring cup)

?
(washer)

78-2027-B
(anchor pin)

?
(pin guide?)

78-2112-B
(pin washer)

33838-S7
(nut 3/4 -16)

78-2035-D
(spring grn)

40-2240-A
(grease baffle)

78-2297-B
(spring org)

33983-S (x4)
(castle nut 1/2 -20)

78-2089-B
(operating lever L.H.)

78-2050
(operating wedge)

78-2011
(backing plate)

1937 Ford Left Front

78-2296-A
(spring blk, primary top)



78-2034-A
(spring red, secondary top)



78-2035-D
(spring grn, primary bottom)



78-2297-B
(spring org, secondary bottom)



78-2036
(spring blk, retracting 5.68")



1937 Ford Brake Springs